



Asus K53E-BBR3 Hard Drive Replacement

After following this guide, the reader will be able to replace their hard drive in their Asus laptop.

Written By: Jacob O'Donnell



INTRODUCTION

Hard drive space is constantly filled up with today's large file sizes. So adding a bigger and better hard drive is a common practice. This guide will demonstrate how to unscrew the back panel from the laptop and then to replace the hard drive.



TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Battery



- Place your laptop face down in front of you.
- Slide the button in the top right corner to the right so that the orange marker is showing.
- Press the spring loaded latch to release the battery from the computer.

Step 2 — Back Panel




- Unscrew two 5mm Phillips #1 screws.

Step 3



- Pull down and lift up on the back panel to remove it.

Step 4 — Hard Drive



- Unscrew the four 5mm Phillips #1 screws.
- Lift the hard drive out of the computer.

Step 5



- Unscrew the screws on the hard drive case.
- Two 3mm Phillips #1 screws are located on one edge of the case.
- The last two 3mm #1 Phillips screws are located on the opposite side of the case.
- After you unscrew all four screws, the metal cage will fall off, leaving you with the hard drive.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 08:35:58 PM.